

Product Name: Sonos Move

Product description Short:

Move, the durable, battery-powered smart speaker for outdoor and indoor listening.

Product description Long:

Get brilliant sound anywhere with the weatherproof and drop-resistant Move. Control with your voice, the Sonos app, and Apple AirPlay 2 at home, and stream via Bluetooth when WiFi isn't available.

Bullet Points:

- Get brilliant sound anywhere with the weatherproof and drop-resistant Move. Control with your voice, the Sonos app, and Apple AirPlay 2 at home, and stream via Bluetooth when WiFi isn't available.
- Experience surprisingly deep bass, a wide soundscape, and automatic Trueplay™ tuning that perfectly balances the sound for where you are and what you're listening to.
- The Google Assistant and Amazon Alexa are built right in so on WiFi you can play music, check news, set alarms, get your questions answered, and more, completely hands-free.
- Stream over WiFi and connect Move to the rest of your Sonos system at home. Switch to Bluetooth when you're away and offline.
- With an IP56 rating, Move stands up to rain, snow, dust, salt spray, UV rays, and extreme heat and cold.

Features:

Weather resistant - Move features an IP56 rating and stands up to humidity, rain, snow, dust, salt spray, UV rays, and extreme heat and cold.

Tunes itself - With automatic Trueplay™ tuning, the microphones detect what you're playing and the environment then automatically adjust to optimize the sound.

Powerful bass - The custom woofer delivers surprisingly rich bass for outdoor listening. Set Move in front of a wall to radiate and produce even deeper sound.

10 hours of battery life - Enjoy up to 10 hours of continuous play time. Recharge with the included charging base or a compatible USB-C charger.

Control at your fingertips - Responsive touch controls on the top of the speaker make it easy to play, pause, skip, adjust the volume, and group rooms.

Grab and go - Move fits seamlessly into the included charging base and features an ergonomic handle, making it easy to pick up and carry.

FAQ:

QUESTION

ANSWER

How do I use Bluetooth?

Once you have set up Move on your WiFi network, press the Bluetooth/WiFi mode button on the back of the speaker to switch to Bluetooth mode. The LED on top of the speaker will illuminate blue. To pair, select Move from the list of available devices on your phone. If it does not appear, press and hold the button.

What does the Sonos app do on Bluetooth?

The Sonos app will control your system on WiFi but not Bluetooth. To listen on Bluetooth, use a streaming service app, such as Spotify.

Does voice control work on Bluetooth?

No. You must be connected to WiFi for the Google Assistant and Amazon Alexa to work on Sonos.

Can I stereo pair Move?

Yes. You can pair two Moves on WiFi for stereo sound.

Can I use two Moves as home cinema surrounds?

No.

Does Move pair with Sub?

No. Because Move is designed to move around your home, pairing with Sub would result in mid and high frequencies in one room and bass in another, resulting in imbalanced sound and an inferior listening experience. You can, however, group Move with a system that includes Sub, such as a 5.1 home cinema setup.

What does the IP56 rating mean?

An IP rating is an international standard that defines how effectively electrical enclosures resist intrusion from foreign elements, such as dust and moisture. The numbers that follow "IP" have specific meanings. The first ranges from 1-7 and defines the degree of protection from foreign elements, such as dust. The second ranges from 1-9 and defines the degree of protection from various forms of moisture, including sprays, drips, and submersion.

Move is rated IP56, meaning it is protected from very fine particles, such as dust, and liquid splashes, including light rain.

Is the charging base weather-resistant?

No. The speaker itself was designed for outdoor use and is therefore resistant to water, dust, and other elements. The charging base, however, should only be used indoors.

Can I take Move to the beach?

Yes.

How long does the battery last?	Move's battery will last for up to 10 hours of uninterrupted. Pausing, volume level, Bluetooth, heat exposure, and other factors will cause battery life to fluctuate. If left off the charging base and unused, the battery will last about 120 hours.
What's the lifespan of Move's lithium-ion battery?	The battery should last about three years or 900 charges, after which you can purchase a replacement battery.
How does auto Trueplay work?	Move's microphones detect what you're playing and measure the frequency response from your surroundings. Using software, the speaker then adjusts its EQ for perfectly balanced sound.
Will auto Trueplay work if the microphones are off?	No. The microphones must be on for auto Trueplay to work.
How often does auto Trueplay adjust the sound?	Auto Trueplay is triggered whenever Move is placed in a new location, and it continuously refines the sound while Move is stationary.
Do the microphones hear commands when audio is playing?	Yes. The far-field microphones in the speaker detect your voice from any direction. You can speak at a natural volume to activate supported voice commands.
Can I turn the microphones off?	Yes. Simply touch the microphone icon and the light will turn off, indicating that the microphones are inactive. The light is hardwired so you know that the microphones are only active when it is illuminated.

Box content:

Sonos Move, Charging Base, QuickStart Guide, Legal & Warranty information

Key Words:

portable wireless speaker,
portable bluetooth speaker,
battery powered wireless speaker,
battery powered bluetooth speaker,
battery powered speaker,
Portable speaker
Bluetooth speakers portable
Wireless speakers bluetooth